

Instructions for:

MOISTURE BARRIER KIT

Approximate time: 10-15 minutes



RAINBOW TECHNOLOGY
Specialists in Utility Chemicals & Safety Items

Step 1:

Put Template (flat box) by the opening/void in the concrete pad inside cross-connect cabinet over the hand hole.



Step 2:

Cut out area for conduits/cables and position Template around ducts/cables as tightly as possible.



Step 3:

Push the Template down into the void; allow 3"-4" of concrete above sides of Template which will allow the Foam to adhere to the concrete.



Step 4:

Tape Template to sides of concrete every 6".



Step 5:

Put tape around ducts/cables and Template to securely seal any cracks that will allow moisture to penetrate the Foam.



Step 6:

After Template is in place and tape is in place, use knife to cut 4"x4" notches in Template to allow proper Foam adhesion to the sides of the concrete.



Step 7:

Mix the 1-Cubic Foot Kit of Pole Foam following label directions and pour on Template with a side-to-side motion. Use the entire container. Do not put the top back on the container. Dispose of empty container in trash.



Step 8:

The Pole Foam will begin to rise immediately. Pole Foam will expand approximately 15 times its original volume.



RAINBOW TECHNOLOGY
Specialists in Utility Chemicals & Safety Items

1.800.637.6047
www.rainbowtech.net